



DESCRIPTION:

CHEMLEASE PMR is a unique semi permanent mold release system developed specifically for the polyester molding industry.

BENEFITS:

- ••Multiple releases between applications
- ••Easy to apply
- ••Eliminates the use of wax
- ••Reduces labor time and costs
- •• Provides excellent gloss
- •• High temperature stability 850°F-450°C
- •• Does not build up on the mold surface
- Does not transfer to molded part

Chemlease solvent carriers contain no Class I or II registered ozone depleting substances

PMR SERIES PRODUCTS:

••CHEMLEASE PMR

High gloss, Class A mold release for the polyester/composite molder. Suitable for 98% of molding applications.

•• CHEMLEASE PMR - 90

Highest slip version of PMR; primarily for closed molding of abrasive, low draft parts, where a quality finish is still required.

MOLD PREPARATION:

- 1. Mold surfaces should be thoroughly cleaned to remove all traces of wax, release agents, sealers and buffing compounds.
- 2. Do a final cleaning of mold surface with CHEMLEASE MOLD CLEANER.
- 3. Seal mold with CHEMLEASE 15 SEALER. (See 15 Sealer Technical Data Sheet for details.)

APPLICATION FOR BASE COATS:

- 1. Mold surface must be thoroughly cleaned to remove all traces of wax, release agents, and other sealers.
- 2. Surface should be dry and free of contaminants.
- 3. Saturate clean cotton cloth (not dripping) and wipe on a smooth continuous film. Apply no more than a few square feet at a time.
- 4. Wait 15-20 seconds. While film is still wet, wipe the surface with a second clean dry cotton cloth using a circular motion from the outside, working inwards until film is left dry and clear. See **Notes** on back.
- 5. Repeat above procedures until entire mold surface has been covered.
- 6. Apply 4-5 coats, allowing 10 minutes between each complete coat.
- 7. Allow 20-30 minutes for full cure. Proceed with production.

NOTES:

Time will vary with room and mold temperature. Wipe off as the solvent begins to evaporate. If the release agent is left on too long, you may notice some smearing or streaking. To remove the smear or streak, rub the affected area with the recommended CHEMLEASE release agent, then simply remove the excess sooner than you had before.

(Continued on Back)



TEST TO ENSURE PROPER APPLICATION:

Attach a small strip of masking tape to different areas of the mold. There should be very little resistance when removing the tape if proper release is applied. Compare to an untreated mold. (Tape should adhere to untreated mold).

TOUCH UP COATS:

Once in production the release film will begin to wear. Rather than applying a touch-up coat once the parts begin to stick, it is better to do preventative maintenance. For example, if trials determine that 20 releases are obtainable between touch-up coats, it is better to reapply a touch-up coat after every 15 cycles or at the end of every second shift if you are, for example, turning the molds 8 times per shift. The above described action will keep the molds in production longer and help establish a routine of quality preventative maintenance.

COATING PATCH REPAIRS:

Prior to repairing a patch, make sure the release is removed for 3-4 inches around the area to be repaired. Note: Semi permanent releases must be removed with mild abrasion as well as a solvent wipe. If not, the patch will not bond to the surface and break out. Once the patch is cured, treat the area as a new mold:

- 1. Clean with CHEMLEASE Mold Cleaner;
- 2. Apply #15 Sealer and cure per instructions;
- 3. Apply 5 coats of PMR release agent and cure.

Touch up the patched area with PMR every other cycle for the first 4-6 releases.

Remember, the patch is weaker than the rest of the mold and will require extra attention for the first few cycles. Further, a touch-up coat (other than patch repair) should usually be done over the whole mold. This prevents having to re-touch another area that is wearing on the next cycle. However, there may be some areas of surface draft, etc. That may require a touch up more frequently. For example:

- •Touch up complete mold every 16 cycles;
- • Touch up small areas with difficult draft angles every 8 cycles.

The PMR is designed to blend into itself very easily and operator experience will quickly determine the number of cycles between spot and complete touch-up. For a spot touch-up, only the 10-minute room temperature cure time is needed.

Whenever the mold is stripped, reapply 15 Sealer and/or the PMR base coats as described.

PACKAGING:

CHEMLEASE materials are available in 1, 5, and 55 gallon containers.

It is important that the materials be left in the factory containers as the product is susceptible to moisture contamination if the container is left open or the material is stored in the wrong type of container. The material should always be clear. If cloudiness is detected, please contact a Chemlease Technical Representative.

SAFETY DATA:

OTT BADER

Material Safety Data Sheets are available for all Chemlease products and should be consulted prior to use of the product.

Revised 03/01/06

PMR

Represented by: 1 Lubex Rd, Hammarsdale, KwaZulu-Natal, South Africa

P. O. Box 1539, Hillcrest. 3650

Tel. 031 736 8500 fax. 031 736 8511

Branches:

Gauteng: tel. 011 8240551, fax.011 8240554
Western Cape: tel. 021 5520970, fax 021 5521031
KwaZulu-Natal: tel. 031 7093879, fax 031 7093882
Eastern Cape: tel. 041 4862455, fax 041 4861982

